

TOYOTA TUNDRA CREWMAX 2014-2021

PLASTIC UNDER SEAT STORAGE

PART# USSCM02

KIT CONTENTS:
UNDER SEAT STORAGE ASSEMBLY
INSTALLATION INSTRUCTIONS
TEMPLATE(PRINTED ON BOX)

TOOLS REQUIRED FOR INSTALLATION:
RAZOR KNIFE
LINOLEUM KNIFE
MARKING CRAYON
SAFETY GLASSES

WARNING!

Installing this product in your

Vehicle requires the use of sharp objects.

***Please make sure you use the proper tools and use
them in a safe manner.***

***We are not responsible for injuries incurred while
installing this product.***



TUNDRA CREWMAX
UNDER SEAT STORAGE
INSTALLATION INSTRUCTIONS

TOOLS NEEDED: RAZOR KNIFE, LIGHT COLORED MARKING CRAYON AND LINOLEUM KNIFE

1. REMOVE ALL CONTENTS FROM BOX
2. USE RAZOR KNIFE TO COMPLETELY CUT OUT CARDBOARD TEMPLATE PRINTED ON INSIDE OF SHIPPING BOX
3. TAKE CARDBOARD TEMPLATE AND PLACE ON FLOOR WITH TOP FACING UP. ALIGN CUTOUTS IN TEMPLATE TO ROUND PART OF THE FRONT OF THE SEAT BASE BRACKETS ON FLOOR OF TRUCK. BUTT THEM UP TO THE EDGE. USE LIGHT COLORED MARKING PEN AND TRACE COMPARTMENT BOX OPENINGS ONTO CARPET
4. USING RAZOR KNIFE CUT OUT CARPET AND REMOVE. !!!NOTE!!! WHEN CUTTING THE CARPET BE VERY PRECISE IN CUTTING ON THE LINES. IT IS VERY IMPORTANT TO THE FIT OF THE STORAGE.
5. **IMPORTANT! IF YOU HAVE A 2020 WITH PUSH BUTTON START, THERE IS A WIRE UNDER THE FRONT CENTER COMPARTMENT. WHEN CUTTING FOAM, START CUTTING FROM DRIVER SIDE TO PASSENGER SIDE. WHEN YOU HIT THE PROTECTOR FOR THE WIRE, MAKE SHALLOW CUTS UNTIL YOU GET THROUGH FOAM TO INSURE NOT NICKING OR CUTTING WIRE. IF BY CHANCE YOU DO CUT THE WIRE, YOU WILL NEED TO SPLICE THE WIRES BACK TOGETHER.**
6. USING THE LINOLEUM KNIFE CUT OUT FOAM FROM FLOOR SAME SIZE OF BOX OPENINGS IN CARPET. REMOVE FOAM.
7. VACUUM ANY LOOSE FOAM LEFT IN OPENING.
8. REMOVE INSULATED BACKING FROM BACK OF CARPETED SQUARES AND PLACE INSIDE THE OPENINGS IN FLOOR.
9. PLACE STORAGE INTO THE OPENING IN THE FLOOR AND EVENLY TAP DOWN THE STORAGE WITH YOUR PALM.
10. AT THIS POINT YOU SHOULD BE DONE. IF BY CHANCE THERE IS SOME LOOSNESS ON THE ENDS, YOU CAN USE BARBED PUSH IN CLIPS AVAILABLE FROM YOUR LOCAL AUTO PARTS STORE. REMOVE STORAGE BACK OUT AND DRILL ONE HOLE IN EACH OUTBOARD SIDE OF THE STORAGE A BIT LARGER THAN THE CLIP.

11. REINSTALL STORAGE BACK INTO THE FLOOR AND PUSH THE CLIPS INTO THE FOAM. THIS WILL HOLD THE STORAGE IN PLACE IF NEEDED.

IF AT ANYTIME, YOU NEED HELP WHILE PERFORMING THE INSTALL, FEEL FREE TO CALL OR TEXT EARL AT 951-858-3418. WE WILL BE HAPPY TO HELP

THANKS FOR YOUR PURCHASE