

CHEVROLET COLORADO/GMC CANYON CREWCAB

2015-CURRENT

UNDER SEAT STORAGE

PART# USSCOL-01

KIT CONTENTS:
UNDER SEAT STORAGE ASSEMBLY
HARDWARE KIT---CONTAINS 2 M10X1.5X50 BOLTS AND 2 M10 FLAT WASHERS
INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION:
RATCHET
8MM SOCKET
10MM SOCKET
13MM DEEP SOCKET
17MM SOCKET
T50 TORX SOCKET
SAFETY GLASSES

WARNING!

Installing this product in your

Vehicle requires the use of sharp objects.

***Please make sure you use the proper tools and use
them in a safe manner.***

***We are not responsible for injuries incurred while
installing this product.***



CHEVROLET COLORADO/GMC CANYON CREW CAB 2015-CURRENT

UNDER SEAT STORAGE

INSTALLATION INSTRUCTIONS

TOOLS NEEDED: 8MM SOCKET, 10MM SOCKET, 13MM DEEP SOCKET, 17MM SOCKET, T50 TORX SOCKET, RATCHET, REMOVE ALL CONTENTS FROM BOX

1. REMOVE 4 10MM PLASTIC ANCHORS ON SIDES OF FACTORY INSTALLED STORAGE (2 ON EACH SIDE). THESE WILL NOT BE REUSED.
2. REMOVE ALL BLACK RUBBER BUMPERS FROM FRONT AND REAR OF FACTORY STORAGE USING 8MM SOCKET, INSTALL 5 OF THEM BACK INTO THE ESP UNIT.
3. REMOVE BLACK PLASTIC FACTORY STORAGE BOX BY PULLING IT OUT. WILL BE LOOSE AFTER ALL OF THE BUMPERS ARE REMOVED.
4. REMOVE THE TWO FRONT M10 TORX HEAD BOLTS FROM FRAME OF THE STORAGE SYSTEM.
5. LOCATE THE METAL STRAP ATTACHED TO THE FRAME, FIND AND REMOVE THE 13MM NUTS THAT ARE UNDER THE FLAP IN THE CARPET.
6. REMOVE METAL FRAME BY PULLING THE STRAPS OFF THE STUDS.
7. USING THE KEYS, UNLOCK THE LIDS ON THE ESP SYSTEM, AND PLACE THE SYSTEM INTO THE TRUCK. POSITION THE FRONT BOLT HOLES IN BOTTOM OF STORAGE OVER THE BOLT HOLES IN THE FLOOR OF THE TRUCK.
8. INSTALL THE SUPPLIED M10 BOLTS AND WASHERS THROUGH THE ESP SYSTEM INTO THE FACTORY HOLES IN THE FLOOR AND TIGHTEN DOWN USING 17MM SOCKET. THE HOLES ARE SLOTTED FOR FORWARD ADJUSTMENT. WHEN TIGHTENING DOWN, THE BOLTS WILL NOT TIGHTEN COMPLETELY DUE TO THE FOAM UNDER THE CARPET. TIGHTEN UP TO WHERE YOU FEEL COMFORTABLE.
9. ENJOY YOUR NEW LOCKING UNDER SEAT STORAGE!