

RAM CREW CAB LOCKING FLOOR BOX 2009-2018

PART# RAM-01

KIT CONTENTS:
FLOOR STORAGE WITH GASKET
HARDWARE BAG-2 KEYS, 2 M6 CAP HEAD SCREWS
INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION:
T-30 TORX BIT
#4 ALLEN WRENCH
SAFTEY GLASSES



RAM CREW CAB LOCKING FLOOR BOX

INSTALLATION INSTRUCTIONS

TOOLS NEEDED: T-30 TORX SOCKET, #4 ALLEN WRENCH

1. REMOVE ALL CONTENTS FROM BOX
2. INSPECT CONTENTS
3. REMOVE REAR FLOOR MAT
4. OPEN FACTORY STORAGE BOX AND REMOVE THE 4 T-30 SCREWS HOLDING COVER ON
5. REMOVE THE TWO SCREWS ON SIDES AND REMOVE THE BOX AND FELT LINER
6. POSITION GASKET UNDER CARPET WITH EDGE CONTAINING THE SIX HOLES TOWARD THE INSIDE OF CAB.
7. INSTALL THE TWO M6 SCREWS INTO THE COUNTERSUNK HOLES ON STORAGE BOX. DO NOT TIGHTEN YET
8. INSTALL ORIGINAL SCREWS ON THE REAR EDGE OF STORAGE BOX. NOTE: THESE SCREWS WILL BE SEEN
9. TIGHTEN DOWN ALL FOUR SCREWS EVENLY IN AN X PATTERN. MAKE SURE THE SCREWS ARE TIGHT BUT DO NOT OVER TIGHTEN THEM
10. CHECK FUNCTION OF LOCK AND ENJOY!

IF AT ANYTIME, YOU NEED HELP WHILE PERFORMING THE INSTALL, FEEL FREE TO CALL OR TEXT EARL AT 951-858-3418. WE WILL BE HAPPY TO HELP

THANKS FOR YOUR PURCHASE