

2019-CURRENT RAM CREWCAB LOCKING UNDER SEAT STORAGE

PART# USSRAM-02

KIT CONTENTS:
UNDER SEAT STORAGE ASSEMBLY AND BRACKETS
HARDWARE KIT---CONTAINS 4 5/16-18 X ¾ CARRIAGE BOLTS, 4 5/16-18 NYLOC NUTS AND 4 3/8" FLAT WASHERS
INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION:
RATCHET
10MM 12 POINT SOCKET
FLAT BLADE SCREWDRIVER (IF EQUIPPED WITH FACTORY COLLAPSABLE UNDER SEAT STORAGE)
T-20 TORX BIT (IF EQUIPPED WITH FACTORY COLLAPSABLE UNDER SEAT STORAGE)
1/2 INCH SOCKET

WARNING!

Installing this product in your

Vehicle requires the use of sharp objects.

***Please make sure you use the proper tools and use
them in a safe manner.***

***We are not responsible for injuries incurred while
installing this product.***



RAM CREWCAB LOCKING

UNDER SEAT STORAGE

INSTALLATION INSTRUCTIONS

TOOLS NEEDED: 10MM SOCKET, T20 TORX SOCKET, RATCHET, FLAT BLADE SCREWDRIVER AND 1/2 INCH SOCKET. REMOVE ALL CONTENTS FROM BOX

1. REMOVE CONTENTS FROM THE BOX
2. FLIP UP BOTH REAR SEATS
3. IF YOUR TRUCK IS EQUIPPED WITH THE COLLAPSABLE PLASTIC UNDER SEAT STORAGE, ROTATE AND RELEASE THE RETAINER IN THE MIDDLE OF THE STORAGE UNIT TO THE OPEN/FORWARD POSITION.
4. REMOVE THE BOLTS FROM THE END PLATES THAT HOLD THE STORAGE TO THE SEAT MOUNTS ON EACH SIDE OF THE UNIT. THERE ARE THREE BOLTS THAT HOLD EACH SIDE.
5. REMOVE IT BY PRYING ONE OF THE END PLATES TOWARD THE CENTER OF THE VEHICLE AND PIVOTING THAT END OF THE UNIT TOWARDS THE FRONT OF THE TRUCK.
6. ONCE YOU REMOVE IT, THE END PLATES MAY BE REMOVED FROM THE UNIT BY REMOVING THE PIVOT BOLTS. THE END PLATES MAY THEN BE REINSTALLED TO THE TRUCK USING THE ORIGINAL HARDWARE REMOVED IN STEP 4.
7. REMOVE THE PLASTIC COVER THAT SURROUNDS THE RETAINER BY GENTLY PULLING TO RELEASE THE PRESSURE CLIPS. THEN REMOVE THE TWO T-20 TORX SCREWS.
8. REMOVE THE OUTER 10MM SEAT MOUNTING BOLTS ON BOTH DRIVER SIDE AND PASSENGER SIDE BRACKETS.
9. AT THIS TIME TAKE THE MOUNTING BRACKET FOR THE PASSENGER SIDE (THE ONE THAT HAS THE LARGE HOLE FACING OUT TO THE DOOR, AND SLIDE IT UNDER THE PASSENGER SIDE SEAT BRACKET. DO THE SAME FOR THE DRIVER SIDE. REINSTALL BOTH OF THE 10MM SEAT BOLTS BUT DO NOT TIGHTEN YET.
10. PLACE THE STORAGE UNIT IN THE TRUCK AND LINE UP THE SQUARE HOLES IN THE BOX TO THE BRACKETS.
11. INSTALL THE 4 5/16-18 CARRIAGE BOLTS THROUGH THE BRACKET INTO THE STORAGE BOX AND INSTALL THE 3/8 WASHER AND 5/16-18 NYLOC NUTS AND TIGHTEN DOWN.
12. TIGHTEN THE TWO 10MM SEAT BRACKET BOLTS.
13. ENJOY YOUR NEW ESP TRUCK ACCESSORIES LOCKING UNDER SEAT STORAGE!