

# TOYOTA TUNDRA CREWMAX 2014-2021

## UNDER SEAT STORAGE

---

**PART# USSCM-01**

<b>KIT CONTENTS:</b>
<b>UNDER SEAT STORAGE ASSEMBLY WITH KEYS</b>
<b>INSTALLATION INSTRUCTIONS</b>
<b>TEMPLATE(PRINTED ON BOX)</b>

<b>TOOLS REQUIRED FOR INSTALLATION:</b>
<b>17MM SOCKET</b>
<b>RATCHET</b>
<b>RAZOR KNIFE</b>
<b>LINOLEUM KNIFE</b>
<b>TORQUE WRENCH</b>
<b>SAFTEY GLASSES</b>
<b>PROTECTIVE BLANKET</b>

**WARNING!**

***Installing this product in your***

***Vehicle requires the use of sharp objects.***

***Please make sure you use the proper tools and use  
them in a safe manner.***

***We are not responsible for injuries incurred while  
installing this product.***



TUNDRA CREWMAX  
UNDER SEAT STORAGE  
INSTALLATION INSTRUCTIONS

TOOLS NEEDED: RAZOR KNIFE, 17MM SOCKET, RATCHET, TORQUE WRENCH, LIGHT COLORED MARKING PEN AND LINOLEUM KNIFE

1. REMOVE ALL CONTENTS FROM BOX
2. USE RAZOR KNIFE TO COMPLETELY CUT OUT CARDBOARD TEMPLATE PRINTED ON INSIDE OF SHIPPING BOX MAKE SURE TO CUT AN X MARKED SLIT IN TEMPLATE FOR OUTER SEAT BOLT HOLES.
3. REMOVE 8 17MM SEAT MOUNTING BOLTS AND NOTE POSITION OF EACH BOLT AS THERE IS ONE BOLT THAT IS NOT THE SAME AS THE OTHER.(DRIVERS SIDE REAR INNER BOLT)
4. LIFT UP ON REAR SEATS AND SLIDE BACK TO EXPOSE FRONT SEAT BOLT HOLES IN FLOOR
5. TAKE CARDBOARD TEMPLATE AND PLACE SLOTTED/HOLES OVER BOLT HOLES IN FLOOR OF TRUCK AND CENTER. PLACE A SEAT BOLT IN THE TWO OUTBOARD BOLT HOLES TO KEEP TEMPLATE IN PLACE
6. USE LIGHT COLORED MARKING PEN AND TRACE COMPARTMENT BOX OPENINGS ONTO CARPET
7. USING RAZOR KNIFE CUT OUT CARPET AND REMOVE. **VERY IMPORTANT! ON 2020 MODELS EQUIPPED WITH SMART KEY, SKIP STEP 8!(SEE STEP 13)**
8. USING THE LINOLEUM KNIFE CUT OUT FOAM FROM FLOOR SAME SIZE OF BOX OPENINGS IN CARPET. REMOVE FOAM.
9. VACUUM ANY LOOSE FOAM LEFT IN OPENING.
10. PLACE STORAGE SYSTEM INTO BOX OPENINGS AT ANGLE WITH REAR OF STORAGE ANGLED UP.
11. REINSTALL REAR SEAT RAIL IN BETWEEN BRACKET ON STORAGE AND TOP OF STORAGE. !!!HINT!!! THIS IS EASIER WHEN THERE ARE TWO PEOPLE.
12. LINE UP ALIGNMENT PIN INTO HOLE IN FLOOR AND PUSH STORAGE INTO FLOOR SITTING FLUSH ON TOP OF CARPET.
13. **TAKE CAUTION CUTTING CENTER FOAM. CUT ON LINES FROM CUTTING FROM DRIVER SIDE TO PASSENGER SIDE. DO NOT CUT ALL THE WAY THROUGH. PULL UP FROM BACK OF FOAM AND BREAK OUT.(ONLY IF EQUIPPED WITH SMART KEY) DUE TO SMART KEY ANTENNA**
14. REINSTALL SEAT BOLTS IN CORRECT POSITIONS AND TORQUE ALL 8 BOLTS TO 31 FT-LB OF TORQUE

VIDEO LINK OF INSTALLATION <http://youtu.be/05uSyq04NwQ>